

Export to Excel directly from a Tools 2.0 template

1. Select or highlight the standard you want to export to Desktop Explorer.
2. In the batch portion of the grid right click and choose "Export All"
3. A dialogue box will pop up where you can name and save the .xls excel file.
4. You can then attach this file to an e-mail to send this information.

The screenshot shows the datacolor TOOLS software interface. The main window displays a data grid with columns for Standard Name, CIE DL, CIE Da, CIE Db, CIE DC, CIE DH, CIE DE, and CMC DE. A context menu is open over the grid, showing options like Grid Configuration, Current Batch, Reset Grid, Print, Export, Export All, Switch, and Save as template. The 'Export All' option is highlighted.

Std. CIE L	Std. CIE a	Std. CIE b	Std. CIE C	Std. CIE h
40.55	-26.01	14.79	29.92	150.39

Batch Name	CIE DL	CIE Da	CIE Db	CIE DC	CIE DH	CIE DE	CMC DE
AB2	-0.37	-1.04	0.08	0.94	0.44	1.10	0.58
AB3	1.03	0.05	-0.74	-0.40	0.62	1.27	0.70
AB4	1.24	-0.16	-0.02	0.13	0.10	1.25	0.65
ABC1	-0.08	0.63	-0.70	-0.89	0.30	0.95	0.49
ABC2	1.47	-0.24	-0.38	0.03	0.45	1.53	0.81
ABC3	1.27	-0.78	0.11	0.73	0.29	1.49	0.77
ABC4	0.23	0.12	-0.65	-0.42	0.51	0.70	0.41
ABC5	1.34	-0.98	-0.86	0.45	1.23		
B11	0.96	-0.92	0.45	1.02	0.06		
B12	1.19	0.29	-0.46	-0.48	0.26		

The screenshot shows a Windows 'Save As' dialog box. The file name is '30286STDwbatches.xls' and the save as type is 'Excel 2003 file (*.xls)'. The dialog is open in the 'Documents' folder, showing a list of files and folders in the 'Documents library'.

5. If you open up the excel file you will have exported exactly the standard and batch grids for the standard and batches.(See below) As was displayed in Tools.

The screenshot shows an Excel spreadsheet titled "test ExcelDocument.xlsx". The active cell is A1, containing the formula "Std. CIE L". The spreadsheet contains two main data tables. The first table, starting at row 1, has columns for "Std. CIE L", "Std. CIE a", "Std. CIE b", "Std. CIE C", and "Std. CIE h". The second table, starting at row 4, has columns for "Batch Name", "CIE DL", "CIE Da", "CIE Db", "CIE DC", "CIE DH", "CIE DE", and "CMC DE".


	A	B	C	D	E	F	G	H
1	Std. CIE L	Std. CIE a	Std. CIE b	Std. CIE C	Std. CIE h			
2	40.55	-26.01	14.79	29.92	150.39			
3								
4	Batch Name	CIE DL	CIE Da	CIE Db	CIE DC	CIE DH	CIE DE	CMC DE
5	AB2	-0.37	-1.04	0.08	0.94	0.44	1.10	0.58
6	AB3	1.03	0.05	-0.74	-0.40	0.62	1.27	0.70
7	AB4	1.24	-0.16	-0.02	0.13	0.10	1.25	0.65
8	ABC1	-0.08	0.63	-0.70	-0.89	0.30	0.95	0.49
9	ABC2	1.47	-0.24	-0.38	0.03	0.45	1.53	0.81
10	ABC3	1.27	-0.78	0.11	0.73	0.29	1.49	0.77
11	ABC4	0.23	0.12	-0.65	-0.42	0.51	0.70	0.41
12	ABC5	1.34	-0.98	-0.86	0.45	1.23	1.87	1.08
13	B11	0.96	-0.92	0.45	1.02	0.06	1.40	0.71
14	B12	1.19	0.29	-0.46	-0.48	0.26	1.31	0.68
15	B13	1.01	-1.15	-0.95	0.56	1.38	1.80	1.08
16	B14	1.13	-0.83	0.39	0.92	0.07	1.46	0.74

The screenshot shows a software interface titled "DC QC 3 View Panel Screen Template". It displays a zoomed-in view of the data from the Excel spreadsheet. The top table shows standard data with columns "Std. CIE L", "Std. CIE a", "Std. CIE b", "Std. CIE C", and "Std. CIE h". The bottom table shows batch data with columns "Batch Name", "CIE DL", "CIE Da", "CIE Db", "CIE DC", "CIE DH", "CIE DE", and "CMC DE".

	Std. CIE L	Std. CIE a	Std. CIE b	Std. CIE C	Std. CIE h
	40.55	-26.01	14.79	29.92	150.39

	Batch Name	CIE DL	CIE Da	CIE Db	CIE DC	CIE DH	CIE DE	CMC DE
	AB2	-0.37	-1.04	0.08	0.94	0.44	1.10	0.58
	AB3	1.03	0.05	-0.74	-0.40	0.62	1.27	0.70
	AB4	1.24	-0.16	-0.02	0.13	0.10	1.25	0.65
	ABC1	-0.08	0.63	-0.70	-0.89	0.30	0.95	0.49
	ABC2	1.47	-0.24	-0.38	0.03	0.45	1.53	0.81
	ABC3	1.27	-0.78	0.11	0.73	0.29	1.49	0.77
	ABC4	0.23	0.12	-0.65	-0.42	0.51	0.70	0.41
	ABC5	1.34	-0.98	-0.86	0.45	1.23	1.87	1.08
	B11	0.96	-0.92	0.45	1.02	0.06	1.40	0.71
	B12	1.19	0.29	-0.46	-0.48	0.26	1.31	0.68

- You may also export multiple standards and batches at the same time if you Right click in the standard section of the template and uncheck 'Current Standard'. This will export all standards not just the highlighted std.



The excel file will then contain tabs for each standard. (NOTE: I added 'Standard Name' to the grid for Tools so that it would be exported to Excel)

